



2001-2003 Honda CBR600 F4i TI MUFFLER INSTRUCTIONS

Thank you for purchasing the FMF Powercore S muffler for your **01-03 CBR600 F4i**. We have spent countless hours of design work and testing to insure you receive the highest quality product on the market today.

Your Powercore S muffler has been developed using the latest design, testing and manufacturing technologies. It is manufactured from a patent pending round to oval titanium canister, uses our hi-flo square core and has a TIG welded CNC bent titanium mid pipe. The Powercore S muffler is designed to broaden your existing powerband and give you an all around power increase.

Check out our website www.fmfracing.com for images, dyno charts and tons more info

If you have any suggestions send them to suggestions@fmfracing.com

Please read all instructions thoroughly before installation. Failure to follow all installation instructions completely will void any FMF warranty implied or otherwise. FMF Racing will not be held responsible for problems derived from improper installation and/or improper usage.

Before you begin installing this product, be sure you are wearing **eye protection** and gloves. You should have a complete understanding of how to remove and replace your stock exhaust. If you do not, you should have it installed by a professional mechanic. Keep all OEM parts when removing your stock exhaust, as some parts may be utilized with the FMF exhaust depending on your particular application.

PARTS SUPPLIED

- | | |
|---------------------------|-----------------------------|
| (1) Medium Strap Bracket | (1) Stainless T-bolt Clamp |
| (1) Rubber Bracket Sleeve | (1) 8mm X 45mm Muffler Bolt |
| (2) 70mm Exhaust Springs | (1) 8mm Flanged Nut |

TOOLS REQUIRED

- | | |
|-----------------|-----------------------|
| 11mm Wrench | Hi-temp Silicon |
| 12mm Wrench | Exhaust Spring Puller |
| 17mm Wrench | Anti Seize Compound |
| Contact Cleaner | WD-40® |

REMOVAL

OEM = Original Equipment Manufacturer

- 1] Loosen the OEM header clamp at the front of the muffler.
- 2] On California models you will need to remove the oxygen sensor using a 17mm wrench. Be careful not to damage the sensor.
- 3] While supporting the muffler, loosen and remove the rear OEM muffler bolt & nut using the appropriate wrenches.
- 4] Gently slide the muffler rearward to release it from the header. Spray WD-40® on the joint if it is difficult to remove.
- 5] Make sure the OEM muffler gasket is removed from the header as it will NOT be used with the FMF exhaust. Depending on the condition of the gasket, it may be difficult to remove.

PRE-INSTALLATION

- 6] Install the rubber sleeve onto the strap bracket so that the rubber is facing inward. Make sure the outer lip is over the bracket edge fully. No rubber should be in the area where the bracket tabs pinch together.
- 7] Use contact cleaner to clean the area in which the exhaust slips over the header.
- 8] Using a 17mm socket, on California models you will need to remove the oxygen sensor plug we have pre-installed on the mid-pipe. On Non-California models you will need to tighten the O2 sensor plug to 40 ft/lbs of torque.

INSTALLATION

- 9] Lightly coat the header with a bead of high temp. silicon where the exhaust inlet slips over.
- 10] Loosely install the supplied stainless t-bolt clamp onto the FMF mid-pipe.
- 11] Slip the FMF mid-pipe inlet over the header until it is fully seated. (The inlet is the side with the notches)
- 12] On California models you will need to lightly coat the threads of the oxygen sensor with anti seize compound, install it in the mid-pipe and tighten to the manufacturers torque specifications. (make sure not to get any grease, dirt, oil, anti seize compound on the actual O2 sensor)
- 13] Lightly coat the mid-pipe with a bead of high temp. silicon where the muffler inlet slips over.
- 14] With clean hands, gently slip the FMF muffler onto the mid-pipe. The FMF logo should be at 3 o'clock when looking from the rear for proper positioning.
- 15] While supporting the muffler, install the two (2) exhaust springs from the muffler to the mid-pipe using a spring puller tool. (One spring on top, one on bottom)
- 16] Slide the rubber sleeved strap bracket carefully over the muffler and position it to the rear upper mounting point. Be careful not to scratch the canister and make sure the "inside" sticker on the bracket is towards the subframe. The strap bracket goes on the outside of the mount.
- 17] Pinch the strap bracket tabs together and install the supplied 8mm nut and bolt to the rear mount. Do not fully tighten at this time.
- 18] Slowly tighten all mounting fasteners and clamps to OEM specified torque specs, starting from the front and working back. Make sure the header and muffler are in neutral positions and not binding.
- 19] Inspect the complete exhaust to make sure the exhaust system is not in contact with the frame, swingarm, engine or any cables, hoses or wiring. The exhaust system should only be in contact with the exhaust port and mounting points. Confirm all controls operate in accordance with the manufacturer's specifications.

POST-INSTALLATION

- 20] Before starting the engine, clean the entire exhaust to remove all dirt and oil residue. This will prevent staining of the metal when it heats up. Windex® works great on the muffler canister.
- 21] Start the engine and bring it up to operating temperature. Check for exhaust leaks.
- 22] Let engine cool completely and re-torque all mounting hardware to the manufacturers specifications.
- 23] After 50-75 miles of use, re-torque all mounting hardware.

MAINTENANCE

To clean your FMF muffler, simply use soap and water when it becomes dirty. Windex® works great on the muffler canister to prevent streaking and uneven discoloration. Let the exhaust system cool before cleaning. Do not spray cold water onto a hot exhaust. Dry completely to prevent streaking.

We recommend re-packing your Powercore S muffler every 10K-15K miles depending on the type of riding you're doing. This will maintain peak performance and keep the sound level from becoming too loud and/or raspy. If the sound level changes significantly or your muffler canister shows signs of discoloration, this is a sign to inspect the packing material and replace if needed. We recommend using our NEW Premier multi-layer packing material.

To re-pack the muffler, remove the four (4) allen screws from the front of the muffler using a 4mm allen wrench. Do not remove the rear endcap. Gently slide out the front end cap from the muffler canister. Be careful not to damage the muffler. Unwrap the packing from the core and discard. Wrap the core with new packing and secure with a strip of masking tape. Before re-installing the inner core assembly, apply a thin layer of hi-temp silicon on the front end cap where the canister slips over. Slip inner core assembly into canister making sure the perforated core fully seats in the rear endcap. Re-install the allen screws until snug or tighten 1/4 turn after the screw makes contact with the canister.

Disclaimer:

FMF Racing inspects all products prior to packaging and strives toward improving its products. Our guarantee is limited to the replacement of defective products. This limited guarantee is in lieu of all other guarantees or warranties implied or expressed. Buyer assumes all risk for any and all damage caused to himself, a third party and/or property by virtue of failure of this product. We make no warranty as to products distributed by FMF Racing, expressed or implied from our suppliers or 3rd party vendors. This includes, without limitation, any warranties or merchantability and fitness for a particular purpose. All products are offered and designed for use with standard machines. FMF Racing makes no claims as to the products effectiveness on modified machines. FMF Racing is the sole determiner of abuse, misuse, installation errors and modifications. We assume no liability for any errors in listings, specifications, part numbers, prices or model applications. We reserve the right to change specifications, product descriptions, product quality, pricing and application at any time without notice and without further obligation. By installing and/or using an FMF product, you hereby accept and understand these stated terms and conditions and have followed all instructional steps.